

Autonics Intelligent Temperature Transmitter KT-502H

MANUAL



Thank you very much for selecting Autonics products.
For your safety, please read the following before using.

Caution for your safety

- ※ Please keep these instructions and review them before using this unit.
- ※ Please observe the cautions that follow:
- ⚠ **Warning** Serious injury may result if instructions are not followed.
- ⚠ **Caution** Product may be damaged, or injury may result if instructions are not followed.
- ※ The following is an explanation of the symbols used in the operation manual.
- ⚠ **Caution:** Injury or danger may occur under special conditions.

Warning

- In case of using this unit with machinery (Ex: nuclear power control, medical equipment, ship, vehicle, train, airplane, combustion apparatus, safety device, crime/disaster prevention equipment, etc) which may cause damages to human life or property, it is required to install fail-safe device.** It may cause a fire, human injury or damage to property.
- Check explosion-proof standard(Ex d IIC T6) of this unit and do not use it in place where there are flammable or explosive gas, humidity, direct ray the light, radiant heat, vibration and impact etc.** It may cause a fire or explosion.
- Do not connect, inspect or repair this unit when power is on.** It may cause electric shock.
- Wire it properly after checking terminal numbers when connecting power cable and measuring input.** It may cause a fire.
- Do not disassemble the case. Please contact us if it is required.** It may cause electric shock or a fire.

Caution

- Please observe the rated specifications.** It may shorten the life cycle of the product and cause a fire.
- Do not inflow dust or wire dregs into the unit.** It may cause a fire or a malfunction.
- In cleaning unit, do not use water or organic solvent. And use dry cloth.** It may cause electric shock or a fire.

Model: **KT** - **502H** **0** (-270 to 1372, K)^{※1}

Item	Description
① Mounting bracket	0 Without bracket 1 With bracket
② Input range	※ 1: To order this unit, write the temperature sensor type and the input range.

Input type and range

Input type	Input range (°C)	Input range (°F)		
RTD	DPt100Ω	-200 to 850	-328 to 1562	
	DPt500Ω	-200 to 250	-328 to 482	
	DPt1000Ω	-200 to 250	-328 to 482	
	Cu50Ω	-50 to 150	-58 to 302	
	Cu100Ω	-50 to 150	-58 to 302	
	Ni100Ω	-60 to 180	-76 to 356	
	Ni500Ω	-60 to 180	-76 to 356	
	Ni1000Ω	-60 to 150	-76 to 302	
Resistance transmitter	Resistance(Ω)	0 to 400Ω		
		0 to 2000Ω		
	B(PtRh30-PtRh6)	0 to 1820	32 to 3308	
	E(NiCr-CuNi)	-270 to 1000	-454 to 1832	
	J(Fe-CuNi)	-210 to 1200	-346 to 2192	
	K(NiCr-Ni)	-270 to 1372	-454 to 2501	
	N(NiCrSi-NiSi)	-270 to 1300	-454 to 2372	
Thermocouple	R(PtRh13-Pt)	-50 to 1768	-58 to 3214.4	
	S(PtRh10-Pt)	-50 to 1768	-58 to 3214.4	
	T(Cu-CuNi)	-270 to 400	-454 to 752	
	Analog	Voltage	-10 - 75mV	
			-100 - 100mV	
-100 - 500mV				
-100 - 2000mV				

※ The above specifications are subject to change without notice.

Specification

Model	KT-502H	
Power supply	10.5-45VDC (with backlight LCD)	
Display method	PV display part : 7 Segment 5 digit(character size: W4×H8mm), Parameter display part : 14 Segment 8 digit(character size: W2.6×H4.8mm), 52 Bar meter	
Display range	-19999 to 99999	
Setting method	HART-protocol (no setting key)	
Response time	1 sec.	
Input type	RTD	DPt100Ω, DPt500Ω, DPt1000Ω Ni100Ω, Ni500Ω, Ni1000Ω Cu50Ω, Cu100Ω
	Thermocouple	K, J, T, E, N, S, B, R
	Resistance tran. (Ω)	0 to 400 Ω 0 to 2000 Ω
	Voltage trans. (mV)	-10-75 mV -100-100 mV -100-500 mV -100-2000 mV
Output	4-20 mA(2-wire)	
Alarm		Below 3.8mA, Over 20.5mA Sensor break 3.6mA
	Load	max.(V power supply - 7.5V)/0.22A
Galvanic insulation	2KVAC(input/output)	
Environment	Ambient temperature	-20 to 70 °C, storage: 20 to 80 °C
	Ambient humidity	0 to 85%RH
Explosion class ^{※1}		Ex d IIC T6 IP67
Material		Body : Aluminum(AIDc.8S), Cover O-Ring : Buna N
Unit weight		Approx. 1.2 kg

- ※ 1: This Explosion class is acquired and managed by Konics Co., Ltd.
- ※ Environment resistance is rated at no freezing or condensation.

Temperature range setting

Connect a HART communicator and set temperature range as below by a HART communicator.

Online (Generic) 1. Device Setup 2. PV 3. PV Ao 4. PV LRV 5. URV	① Press the <input checked="" type="checkbox"/> key for 3 sec. Select the '4. PV LRV' by ↑, ↓ keys and press the <input type="checkbox"/> key.
SAVE	

1. PV LRV 2. URV	② Select '1. PV LRV'(Low temperature range) and press the <input type="checkbox"/> key.
HELP HOME	

PV LRV 0.000 deg C	③ Set Low temperature range and press the <input type="checkbox"/> (F4) key.
0.000	
HELP DEL ESC ENTER	

1. PV LRV 2. URV	④ Select '2. URV'(High temperature range) and press the <input type="checkbox"/> key.
HELP HOME	

PV URV 100.000 deg C 100.000	⑤ Set High temperature range and press the <input type="checkbox"/> (F4) key.
HELP DEL ESC ENTER	

1. PV LRV 0.000 deg C 2. URV 100.000 deg C	⑥ When the set temperature range is correct, press the <input type="checkbox"/> (F2) key.
HELP SEND HOME	

- WARNING - Pressing 'OK' will change device output put 100P in manual	⑦ Press the <input type="checkbox"/> (F4) key.
OK	

- WARNING - Return control 100P To automatic control	⑧ Press the <input type="checkbox"/> (F4) key.
OK	

1. PV LRV 0.000 deg C 2. URV 100.000 deg C	⑨ Check the set temperature range. Press the <input type="checkbox"/> (F3) key. HART communication is OFF.
HELP HOME	

Current Trim adjustment

Connect a HART communicator and adjust current trim as below by a HART communicator.

1. Device Setup 2. PV 3. PV Ao 4. PV LRV 5. URV	① Select the '1. Device Setup' by ↑, ↓ keys and press the <input type="checkbox"/> key.
---	---

1. Process Variables 2. Diag/Service 3. Basic Setup 4. Detailed Setup 5. Review	② Select the '2. Diag/Service' by ↑, ↓ keys and press the <input type="checkbox"/> key.
---	---

1. Test device 2. Loop test 3. Calibration 4. D/A trim	③ Select the '4. D/A trim' by ↑, ↓ keys and press the <input type="checkbox"/> key.
---	---

WARN-Loop should be removed from automatic control	④ Press the <input type="checkbox"/> (F4) key.
ABORT OK	

Connect reference meter	⑤ Press the <input type="checkbox"/> (F4) key.
ABORT OK	

Setting fid dev output to 4mA	⑥ Press the <input type="checkbox"/> (F4) key.
ABORT OK	

Enter meter Value 4.000	⑦ Press the <input type="checkbox"/> (F4) key to set 4 mA display value.
HELP DEL ABORT ENTER	

Fid dev output 4.000 mA equal to reference meter ? 1. Yes 2. No	⑧ If output display value is correct, select '1. Yes' and press the <input type="checkbox"/> (F4) key. If not, select '2. No' and press the <input type="checkbox"/> (F4) key and re-set the display value. Ex) If output display value is 3.89mA, select 3.89 and press the <input type="checkbox"/> (F4) key.
ABORT ENTER	

Setting fid dev. output to 20mA	⑨ Press the <input type="checkbox"/> (F4) key.
ABORT OK	

Enter meter Value 20.000	⑩ Press the <input type="checkbox"/> (F4) key to set 20mA display value.
HELP DEL ABORT ENTER	

Fid dev output 20.000 mA equal to reference meter ? 1. Yes 2. No	⑪ If output display value is correct, select '1. Yes' and press the <input type="checkbox"/> (F4) key. If not, select '2. No' and press the <input type="checkbox"/> (F4) key and re-set the display value.
ABORT ENTER	

NOTE-Loop may be returned to automatic control	⑫ Press the <input type="checkbox"/> (F4) key.
ABORT OK	


Diag/Service 1. Test device 2. Loop test 3. Calibration 4. D/A trim	⑬ Press the <input type="checkbox"/> (F3) key.
HELP SAVE HOME	

Device Disconnected	⑭ Press the <input type="checkbox"/> (F3) key.
RETRY QUIT	


1. Offline 2. Online 3. Frequency Device 4. Utility	⑮ Press the <input checked="" type="checkbox"/> (F3) key to complete the adjustment.
--	--

Dimensions


(unit: mm)



Opening cover



Connections



Caution for using

- For connecting the power, use a crimp terminal(M3.5, min. 7.2 mm).
- The connection of this unit should be separated from the power line and high voltage line in order to prevent inductive noise.
- Install a power switch or a circuit breaker to supply or cut off the power.
- Switch or circuit breaker should be installed nearby users for convenient control.
- Do not use this unit near the high frequency instruments(high frequency welding machine & sewing machine, large capacity SCR controller).
- Installation environment.
 - Indoor / Outdoor
 - Altitude max. 2,000 m
 - Pollution degree 2
 - Installation category II

※ It may cause malfunction if above instructions are not followed.

Major product

- Photoelectric sensors
- Fiber optic sensors
- Door/Door side sensors
- Area sensors
- Proximity sensors
- Pressure sensors
- Rotary encoders
- Temperature controllers
- Temperature/Humidity transducers
- Switching mode power supplies
- Control switches/lamps/buzzers/sockets
- I/O terminal blocks/cables
- 2/5-phase stepper motors/drivers
- Motion controllers
- Touch Screen/Logic panels
- Field network devices
- Laser marking system (Fiber, CO₂, Nd:YAG)
- Laser welding/soldering system
- SSR/Power controllers
- Counters
- Timers
- Panel meters
- Tacho/Speed/Pulse meters
- Display units
- Sensor controllers
- Recorders
- Indicators
- Converters
- Controllers
- Thyristor units
- Pressure transmitters
- Temperature transmitters

Autonics Corporation
http://www.autonics.com

Satisfiable Partner For Factory Automation

HEAD QUARTERS :
116, Ungbigongdan-gil, Yangsan-si, Gyeongsangnam-do, Korea
OVERSEAS SALES :
#402-404, Bucheon Techno Park, 655, Pyeongcheon-ro, Wonmi-gu, Bucheon, Gyeonggi-do, Korea
TEL : 82-32-610-2730 / FAX : 82-32-329-0728
E-mail : sales@autonics.com

The proposal of a product improvement and development :product@autonics.com

AEP-E-0609